

# easyCover



Product Description	Product code	Barcode (ean 13)	
for Canon 5D mark II	ECC5D2	871772952	1441
for Canon 5D Mark III	ECC5D3	871772952	1632
for Canon 5D Mark III red	ECC5D3R	871772952	1977
for Canon 6D	ECC6D	871772952	1915
for Canon 6D red	ECC6DR	871772952	1984
for Canon 7D	ECC7D	871772952	1380
for Canon 60D	ECC60D	871772952	1458
for Canon 100D / SL1	ECC100D	871772952	2066
for Canon 100D / SL1 red	ECC100DR	871772952	2080
for Canon 550D / T2i	ECC550D	871772952	1403
for Canon 600D / T3i	ECC600D	871772952	1465
for Canon 650D / 700D / T4i / T5i	ECC650D	871772952	1793
for Canon 650D / 700D / T4i / T5i red	ECC650DR	871772952	1922
for Canon 1100D / T3	ECC1100D	871772952	1472
for Canon M	ECCM	871772952	1939
for Nikon V1	ECNV1	871772952	1656
for Nikon J1 / J2	ECNJ1	871772952	1663
for Nikon J3	ECNJ3	871772952	2035
for Nikon S1	ECNS1	871772952	2042
for Nikon D600	ECND600	871772952	1892
for Nikon D600 yellow	ECND600Y	871772952	1908
for Nikon D800/D800E	ECND800B	871772952	1649
for Nikon D800/D800E yellow	ECND800Y	871772952	1885
for Nikon D3100	ECND3100	871772952	1427
for Nikon D3200	ECND3200B	871772952	1670
for Nikon D3200 yellow	ECND3200Y	871772952	1694
for Nikon D5100	ECND5100	871772952	1489
for Nikon D5200	ECND5200	871772952	1960
for Nikon D5200 yellow	ECND5200Y	871772952	1991
for Nikon D7000	ECND7000	871772952	1434
for Nikon D7100	ECND7100	871772952	2059
for Nikon D7100 yellow	ECND7100Y	871772952	2073