

Product designation

Flash trigger

article no. 56.200.00

Product description

The infrared transmitter is used for wireless, synchronized release of the VISATEC flash units by the hot shoe or synchronous contact of the camera. It has a suitable fixation base for the hot shoe with ISO centre contact.

Scope of delivery

Transmitter with 1 sync cable and 2 batteries

Technical data

Range:	10 m
Trigger sequence per s:	1
Dimensions:	115 x 50 x 60 mm (including base)
Weight:	300 g
Power supply:	2 AA alkaline batteries 1,5 V or 2 Batteries AA, NiCd 1,2 V

Compatibility

With the flash trigger you can release VISATEC flash units with an integrated IR-sensitive photocell.

Application

The transmitter is ideal for use in the studio.

Arguments

The transmitter allows shooting without a sync cable and simplifies the work. There are no more invisible "trip wires" and, therefore, no more damaged sync contacts. This freedom of movement is much appreciated, especially in fashion and children photography and on location (interiors).