



salesinfo@chimeralighting.com  
www.chimeralighting.com  
1812 Valtec Lane  
Boulder, Colorado 80301  
Phone: (303) 444-8000  
Fax: (303) 444-8303  
Toll Free: (888) 444-1812

## #1650 LP-1x1 Assembly Instructions



### Contents:

- Lightbank with poles affixed
- Standard #LS30 Front Enhancer Lens Screen
- Security Tab Velcro™ button

- The support poles are already affixed to the Lightbank body. The Lightbank is ready to be mounted into your Speed Ring Frame. Start by opening the relief corner Velcro™ tab on the Lightbank.
- Insert all rods into the Speed Ring Frame at the proper angle leaving the relief corner rod to last.
- Close the relief corner Velcro™ tab.
- Slide the Speed Ring Frame into the channels on your Lightpanels 1x1 Light. The Speed Ring Frame cut outs are positioned at top and bottom of your light. **NOTE: If your Speed Ring Frame does not slide in easily, you may have an older Litepanels model that requires a smaller size frame. Please call for a replacement if this is the case.**
- After peeling off the blue protective film, mount the Standard Front Enhancer Lens Screen to the Lightbank Body with the Velcro™ edges.
- The top Security Tab prevents the Lightbank from sliding off when carried upside down. Affix the supplied Velcro™ button to your light to align with the Security Tab.
- To disassemble, remove the Front Enhancer Lens Screen. Pull the poles out of the frame carefully – one at a time, while maintaining the angle of the pole in the pole hole. Leave the poles in the Lightbank. Always make sure that your Lightbank is clean and completely dry before storing.
- Carefully store your Front Enhancer Lens Screen flat in any secure storage case. Clean your Front Screen with mild cleaning solution and a soft cloth as needed. Optional Front Enhancer Lens Screens available – call for details.

### Dimensions

Front Enhancer Lens Screen: 14.75" x 14.75"

Depth: 7"

### WARRANTY

At CHIMERA, we stand behind our Lightbanks, Speed Rings, and light control accessories with a limited 5-year warranty against defects in materials, workmanship, and color stability. If our products are not fully operational out of the box or if they fail to perform within five years from the date of purchase, return it for repair or replacement. Of course, CHIMERA's warranty cannot cover damage caused by accidents, improper care or use, or the natural deterioration of materials over an extended period of time.